




PAIRING AN UNASSIGNED BROTHER PORTABLE PRINTER WITH THE SCHILLER TOUCH

Printers have been assigned to individual Touch 7 devices and should remain together as a pair. Follow procedure below to pair an unassigned printer to the Touch 7 should this be a requirement.


1. Power up the printer and the touch 7. Wait for 3 dots to change to bars (approx. 20 sec). Once changed select this icon




2. From following menu select 'Printer' (Red X shows printer not found)




3. From following menu select 'Scan for printer'. The Touch 7 will now scan for available printers



4. Once the Touch 7 has found the printer it will denote it by displaying the last 4 numbers of the printer serial number.



5. 'Pairing Successful' will be shown upon completion of the pairing process



Note: If multiple printers are within Bluetooth range, the Touch 7 will display multiple printer options, please make sure you select the correct serial number that matches the printer you wish to pair!